



CE Approved T-Series Tower Dryer

Operation Manual - Original Instructions

PNEG-1797CE

Version: 3.0

Date: 01-10-20



PNEG-1797CE

GSI GROUP



**CE Declaration
MACHINERY DIRECTIVE
2006/42/EC**

1004 East Illinois Street, Assumption, IL, 62510, USA

+1 217 226 4429

We, the GSI Group LLC, declare that

GSI Tower Dryers

With the following model numbers

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
*	*	*	*	*	*	3	S	L	*	E	M	*	*	S	*	*
						6	D	N								
							H	V								

* May be any character

Meet the Essential Requirements of the Machinery Directive 2006/42/EC and has been evaluated to using the following standards:

- EN746-2:2010 *Industrial Thermo Processing Equipment.*
- ISO 14121-1 *Safety of machinery - Risk assessment.*
- EN 60204-1:2006 *Safety of Machinery - Electrical Equipment of Machines.*
- ISO 13849-1:2006 *Safety of machinery - Safety related parts of control systems - Part 1:General principles for design.*

We further declare that the above machines also fulfill the requirements of the Electromagnetic Compatibility Directive (EMC) 2004/108/EC being tested and certified under the following standards by EU Notified Body Intertek Testing Service Inc:

- EN61000-6-2 *Generic standards - Immunity for industrial environments.*
- EN61000-6-4 *Generic standards - Emission standard for industrial environments.*

These declarations apply solely to the equipment as supplied by GSI and described in the attached manual. It does not imply compliance for any equipment connected to or associated with the dryer, modifications of any sort made to the dryer, nor for any electrical, fuel or other energy supplies connected to the incoming terminations on the dryer.

G S I G R O U P



**CE Declaration
MACHINERY DIRECTIVE
2006/42/EC**

1004 East Illinois Street, Assumption, IL, 62510, USA

+1 217 226 4429

The equipment above must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions for all relevant Directives, or until these components have been assembled in the manner recommended in the attached manufacturers instructions.

Signed:

Tower Dryer Gas Train Commissioning Check List and Sign-Off

Component	Set Point	Function Pass/Fail/NA
Check Fuel Supply Shut Off Valve		
Check Main Fuel Supply Pressure		
Set/Test Main Gas Regulator Pressure		
Set/Test Over Pressure Shut Off (OPSO) Pressure		
Set/Test Pressure Relief Valve		
Set/Test Maximum Gas Pressure Switch		
Set/Test Minimum Gas Pressure Switch		
Set Pilot Burner Pressure		
Set Burner High Flame Pressure		
Set Burner Low Flame Pressure		
Test Pilot Line Manual Shut Off Valve		
Test Main Gas Manual Shut Off Valve		
Set/Test Plenum High-Limit		
Carry Out Leak Test		
Check Purge Time		
Check Pilot Ignition		
Check Main Flame Ignition		
Check Modulating Valve Operation		
Check Burner Shut Down		

Name: _____ Signed: _____ Date: _____

All information, illustrations, photos and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Contents

Chapter 1 Safety	7
Safety Guidelines	7
Cautionary Symbols Definitions	8
Safety Cautions	9
Safety Sign-Off Sheet	14
Working at Heights	15
Entering Grain Dryers	16
Precautions to Reduce Risk of Fire	18
Chapter 2 Decals	19
Chapter 3 Specifications	25
Electrical	25
Fuel	26
Dimensions	28
Chapter 4 Dryer Installation	31
Dryer Layout	31
Foundation	31
Standard Base for Models 1050, 1260, 1575, 1875 and 20100	32
Standard Base for Model 24100	33
Fuel Connections	34
Electrical Connection	34
Connecting Auxiliary Conveyors	34
Chapter 5 Operating Controls	35
Vision Control Panel Layout	35
Chapter 6 Vision Touch Screen Display	37
Select Data Log Sample Time	38
Optional Operation Screen	39
Setting the Timers	40
Setting the Temperatures	41
The Setup Screen	42
Viewing the Owner's Manuals on the Display Screen	45
Viewing the Dryer Shut Down History	46
Chapter 7 Dryer Start-Up	47
Dryer Commissioning	47
Pre-Season Checks	51
Tower Dryer Pipe Train Assembly	54
Inlet Section	55
Regulator Section	56
Pilot Section	57
Safety Shut Off Section	58
Modulator Section	59
Chapter 8 Dryer Start-Up and Operation	60
Drying Temperatures	60
Initial Setup Parameters	60
Start-Up	60
Continuous Flow Drying Mode Using Advanced Moisture Control	61
How the Advanced Moisture Control Works	65

Table of Contents

Chapter 9 Drying Time Tables	66
Chapter 10 Service	72
Pre-Seasonal Inspection and Service	72
Seasonal Inspection and Service	72
In Case of Fire	73
End of Season Service	73
Pre-Season Service Check List	74
End of Season Shut Down Procedure	74
Chapter 11 Lubrication	75
Chapter 12 Error Messages	76
Safety Circuit Shut Down Messages	76
Input/Output Generated Errors	77
Master Display Generated Errors	78
Chapter 13 Wiring Diagrams for Pactrol Burner Control	79
Upper Terminal Strip Wiring	79
Burner/Fan Control Wiring	80
Lower Terminal Strip Wiring	81
Safety Relay Wiring	82
Upper Terminal Strip Field Connections	83
Lower Terminal Strip Field Connections	84
Chapter 14 Wiring Diagrams for Honeywell Burner Control	85
Upper Terminal Strip Wiring	85
Burner/Fan Control Wiring	86
Lower Terminal Strip Wiring	87
Safety Relay Wiring	88
Upper Terminal Strip Field Connections	89
Lower Terminal Strip Field Connections	90
Chapter 15 Warranty	91

Safety Guidelines

Safety guidelines are general-to-specific safety rules that must be followed at all times. This manual is written to help you understand safe operating procedures and problems that can be encountered by the operator and other personnel when using this equipment. Read and save these instructions.

As owner or operator, you are responsible for understanding the requirements, hazards, and precautions that exist and to inform others as required. Unqualified persons must stay out of the work area at all times.

Alterations must not be made to the equipment. Alterations can produce dangerous situations resulting in **SERIOUS INJURY** or **DEATH**.

This equipment must be installed in accordance with the current installation codes and applicable regulations, which must be carefully followed in all cases. Authorities having jurisdiction must be consulted before installations are made.

When necessary, you must consider the installation location relative to electrical, fuel and water utilities.

Personnel operating or working around equipment must read this manual. This manual must be delivered with equipment to its owner. Failure to read this manual and its safety instructions is a misuse of the equipment.

ST-0001-4

Cautionary Symbols Definitions

Cautionary symbols appear in this manual and on product decals. The symbols alert the user of potential safety hazards, prohibited activities and mandatory actions. To help you recognize this information, we use the symbols that are defined below.



This symbol indicates an imminently hazardous situation which, if not avoided, **will result in serious injury or death.**



This symbol indicates a potentially hazardous situation which, if not avoided, **can result in serious injury or death.**



This symbol indicates a potentially hazardous situation which, if not avoided, **can result in minor or moderate injury.**




This symbol is used to address practices not related to personal injury.



This symbol indicates a general hazard.



This symbol indicates a prohibited activity.



This symbol indicates a mandatory action.

ST-0005-2

Safety Cautions

Use Personal Protective Equipment

- Use appropriate personal protective equipment:

Eye Protection



Respiratory Protection



Foot Protection



Hearing Protection



Head Protection



Fall Protection



Hand Protection



- Wear clothing appropriate to the job.
- Remove all jewelry.
- Tie long hair up and back.

ST-0004-1

Follow Safety Instructions

- Warning: If the information in the manual is not followed exactly, a fire or explosion can result, causing property damage, personal injury or loss of life.
- Carefully read all safety messages in this manual and safety signs on your machine. Keep signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from the manufacturer.
- Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.
- If you do not understand any part of this manual or need assistance, contact your dealer.
- Retain these instructions for future reference.



ST-0025-3

1. Safety

Install and Operate Gas-Fired Equipment Properly

- Gas-fired equipment should be installed by a qualified pipe fitter and must conform with local codes.
- For Canada: The equipment shall be installed in accordance with the *Natural Gas and Propane Installation Code, CSA B149.1*, or the *Propane Storage and Handling Code, CSA B149.2*, or applicable provincial regulations, which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.
- For the United States: The equipment shall be installed in accordance with the *National Fuel Gas Code ANSI Z223.1/NFPA 54*.



ST-0016-2

For Your Safety

- If you smell gas:
 - Do not try to light any appliance.
 - Extinguish any open flames.
 - Do not touch any electrical switch.
 - Immediately call your gas supplier. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- The use and storage of gasoline and other flammable vapors and liquids in open containers in the vicinity of this appliance is hazardous.
- Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment. Installation and service must be performed by a qualified installer, service agency or the gas supplier.



ST-0024-1

Install and Operate Electrical Equipment Properly

- Electrical controls must be installed by a qualified electrician and must meet the standards set by applicable local codes (National Electrical Code for the US, Canadian Electric Code, or EN60204 along with applicable European Directives for Europe).
- Lock-out power source before making adjustments, cleaning, or maintaining equipment.
- Make sure all equipment and bins are properly grounded.



ST-0075-1

Maintain Equipment and Work Area

- Understand service procedures before doing work.
- Keep area clean and dry.
- Do not service equipment while it is operating. Disconnect and lock-out power and fuel supply before entering equipment or before performing maintenance.
- Keep your equipment in proper working condition. Replace worn or broken parts immediately.
- Depressurize the fuel train before disassembling for service.
- Allow the fan to operate for 20 minutes with the burner off to purge products of combustion and to cool the components before entering.
- Check regularly for any developing gas plumbing leaks. Do not operate the dryer if any gas leak is detected. Shut down and repair before further operation.



ST-0030-2

Exercise Caution When Drying Flammable Grains

- Be aware that some grains are highly flammable including but not limited to rapeseed, canola, linseed, sunflower and milo.
- All grain and seed must be whole (minimal cracking or crushing), clean and dust free before drying.
- Avoid dust and chaff from being drawn into the fan and heater.
- To reduce risk of fire, keep the fan, heater, drying plenum and ducts clean at all times.
- In the event of a fire (or suspected fire):
 1. Shut down the entire dryer.
 2. Turn off the fuel at the tank or supply valve.
 3. Shut off and lock electrical power.
 4. Evacuate the area.
 5. Call the fire department.



ST-0032-1

Fall Hazard

- Keep access door closed while on a platform to avoid falls.
- Always use proper personal protective equipment and proper clothing when using equipment. Failure to follow safety precautions can result in severe injury or death.




ST-0042-2

1. Safety

Maintain Equipment and Work Area

- Equipment is intended for the use of grain drying only. Any other use is a misuse of this equipment.
- The operating instructions in this manual pertain to the common cereal grains as indicated. When drying any other grain, contact GSI for additional recommendations.
- Be certain that capacities of auxiliary conveyors are matched to dryer metering capacities.
- On LP fired units, set pressure regulator to avoid excessive gas pressure applied to the burner during ignition and operation. Do not exceed maximum recommended drying temperatures.
- Equipment has sharp edges that can cause serious injury. To avoid injury, handle sharp edges with caution and use proper protective clothing and equipment at all times.
- All guards must be in place before and during operation. Images of guards removed in this manual are for illustration purposes only.
- Use caution when working around high-speed fans, gas burners, augers and auxiliary conveyors which can start automatically.
- Keep hands, feet, and clothing away from moving parts.
- Do not bypass any safety device or interlock.
- Do not enter the dryer or bin while it is operating.
- Do not operate in an area where combustible material will be drawn into the dryer.



ST-0034-2

Stay Clear of Hoisted Equipment

- Always use proper lifting or hoisting equipment when assembling or disassembling equipment.
- Do not walk or stand under hoisted equipment.
- Always use sturdy and stable supports when needed for installation. Not following these safety precautions creates the risk of falling equipment, which can crush personnel and cause serious injury or death.



ST-0047-1

Confined Space Hazards and Entry Procedures

- Note that the interior of this equipment is considered a confined space. Maintenance of this equipment can require access to the confined space.
- Access doors must be shut and locked except when access is required.
- Doors giving access to dangerous equipment must be safety interlocked.
- The following entry procedures must be followed:
 - Be aware of all possible hazards present inside the confined space and wear personal protective equipment (PPE) as needed.
 - Complete a permit to work and follow all permit required confined space entry procedures defined by the site manager.
 - Make sure that the area has been purged of any hazardous products or gases. Check the atmosphere for harmful gases or vapors with a suitable gas analyzer and make sure levels are safe before entering.
 - Do not smoke or use naked flames.
 - Lock out and tag out power supplies and fuel supplies to all equipment.
 - Do not work alone. Work in teams of at least three so that help is immediately available in the event of an emergency.
 - Confirm that all personnel have safely exited the equipment and tools have been recovered once work is complete.



ST-0055-1

Fall Hazard

- Ladders, stairways and platforms are for use by competent and trained personnel only. Do not allow children or other unauthorized persons to have access to the equipment.
- Access to the equipment must be restricted by the use of security fencing and lockable gates.
- Lower sections of ladders must be fitted with a lockable safety gate to prevent unauthorized access.
- Make sure that hot surfaces have had adequate time to cool before working on or in the equipment.
- Lock out and tag out power supplies and fuel supplies to all equipment.
- Do not attach lifting equipment to ladders or platforms.
- Do not go outside of the safety rails provided on elevated platforms.
- Do not work at heights during high winds, rain, snow, or ice storms.



ST-0056-1

1. Safety

Install and Operate Equipment Properly

- Before attempting to remove and re-install the fan blade, contact GSI for the recommended procedure.



ST-0033-2

Safety Sign-Off Sheet

Below is a sign-off sheet that can be used to verify that all personnel have read and understood the safety instructions. This sign-off sheet is provided for your convenience and personal record keeping.

[illegible]

ST-0007

Working at Heights

Whilst the equipment has been designed to operate primarily at ground level, at some stages during the life cycle it will be necessary to operate at heights. For this reason the equipment has been provided with access ladders, platforms and walkways. These have been designed to recognized safety standards to minimize the risk to health and safety to operators and technicians working on them. In addition attention should be paid to the following safety requirements.

1. The ladders, platforms and walkways are for use by competent and trained personnel only. NEVER allow children or members of the general public to gain access to the equipment, its ladders or access platforms.
2. Where the equipment is sited in an unsecured location, access must be restricted by use of security fencing and lockable gates.
3. Lower sections of ladders on the equipment should be fitted with a lockable safety gate, to prevent unauthorized access.
4. Ensure any hot surfaces have had adequate time to cool before working on or in the equipment. This may require running the equipment fans only to cool off external screens and internal burner components.
5. The equipment should be OFF and all power LOCKED OFF before work on or in the equipment. Ensure the power isolator is OFF and LOCKED and TAGGED to prevent inadvertent re-start. This must include all equipment attached to the dryer/bin on which you are working. (See Figure 1A.)



Figure 1A

6. Ensure the fuel supply is OFF and LOCKED. (See Figure 1B.)



Figure 1B

1. Safety

7. NEVER attach lifting equipment to ladders or platforms.
8. When working on the equipment, NEVER go outside the safety rails provided.
9. NEVER walk on the roof of the equipment.
10. Do not work at heights during high winds, heavy rain, snow, ice or storm.

The majority of routine cleaning and service can be carried out from the service platforms provided. However in exceptional circumstances it may be necessary to access other parts of the equipment. In particular, in the rare event that access is required to repair or replace the grain level switches. On these occasions additional access and safety equipment may be required. Wherever possible we recommend the use of powered access lift platforms or 'cherry pickers'. In exceptional circumstances access may require the use of safety harness. Such work must only be carried out by specialist technicians trained and qualified in working at heights and only after a complete risk assessment has been carried out and safe working methods established.

Entering Grain Dryers

Wherever possible it is recommended not to enter grain dryers. However, if you have to enter the, observe the following minimum precautions:

1. **NEVER** allow a child or untrained, inexperienced person to enter a grain dryer at any time.
2. Make sure you are aware of all the possible **hazards** present within the dryer.
3. Complete a **risk assessment** and identify any control measures that may be required, including:
 - Personal protective equipment, such as hand, eye, foot, hearing, head and respiratory protection.
 - Safe access equipment.
 - Safety equipment, such as safety line and harness.
 - Supplementary lighting.
4. You may need to complete a **permit to work** and prepare a **safe system of work** and have it approved by the dryer owner or supervisor.
5. Ensure the dryer has been purged of any products of combustion. Shut off the burner but leave the fans running for at least 30 minutes before entry.
6. Do not smoke or use naked flames in or around the dryer.
7. Where there is a risk of harmful gases or vapors, check the atmosphere with a suitable analyzer. If necessary, run the fans for longer to provide a safe breathable atmosphere. **If in doubt do not enter.**
8. **Switch OFF, lock and tag** power supplies to **ALL** equipment associated with the dryer. Include equipment feeding and emptying the dryer. This will require turning the main power isolator to **OFF**, **LOCKING** it and apply a **TAG** to prevent inadvertent re-start. (See Figure 1C on Page 17.)



Figure 1C

9. You may also need to lock out any associated equipment attached to the dryer.
10. **Shut OFF, lock and tag** the fuel supply at the main incoming valve. *(See Figure 1D,)*



Figure 1D

11. **Never work alone**, it is recommended to work in teams of at least three (3) so help is immediately available in the event of emergency.
12. On completion of the work, check all team members are out of the dryer and all work tools have been recovered.
13. Close and lock all dryer accesses.
14. Do not re-connect power or fuel supplies until approved by the dryer owner or supervisor.

Precautions to Reduce Risk of Fire

Whilst the dryer has been designed to minimize the risk of ignition of combustible dust and dirt, this can only be ensured by regular inspection and cleaning. **At least every five (5) days.**

1. Refer to [Page 16](#) for required precautions before entering the dryer. The dryer must be locked out and tagged at the main power and fuel supply before entering.
2. Open the dryer access hatches and check for any significant build-up of dust or particles of grain.
3. Using an industrial vacuum cleaner, clean the plenum. **Do not use compressed air.**
4. Check inside other dryer accesses and clean as required.
5. Check all personnel are out of the dryer, close and lock all accesses before re-starting drying.
6. This procedure may be carried out more regularly in conditions of extreme dust and dirt.

Exercise greater caution when drying highly flammable grains and seeds. For example rapeseed, canola, linseed, sunflower and milo.

All grain and seed must be whole (minimal cracked or crushed), clean and dust free.

Dry at low temperatures (< 40°C).

Avoid dust and chaff being drawn into the fan and heater.

Keep the fan, heater, drying plenum and ducts clean at all times.

In the event of a fire (or suspected fire).

- Shut down the entire dryer.
- Turn OFF fuel at the tank or supply valve.
- Shut off and lock electrical power.
- Evacuate the area.
- Call the fire department.

Safety decals must be read and understood by all people in and around the dryer area. If any safety decals are not displayed on the dryer or if they are damaged, contact The GSI Group, Inc. for replacement:

International Decals

International, translated versions of the decals fitted to the equipment are available as part of the Language Pack that was supplied with the product. If you need further copies or a different language, please contact GSI or your dealer.

The international decals have been designed to be placed directly over the USA standard versions. Normally these will be factory fitted, but if you need to change them, please refer to the decal cross reference sheet, provided with the Language Pack and the decal locations given in the user's manual.

Decals


1004 E. Illinois St.
Assumption, IL. 62510
Phone: 1-217-226-4421



2. Decals



- Automatic Machinery
- Automatické stroje a zařízení
- Automatikus Machinery
- автоматични машини
- automatische machines
- Автоматические машины
- автоматичні машини
- Automātiskā Mašīnas
- Automatinis Machinery
- machines automatiques
- Maquinaria automática
- macchina automatica
- automatiska maskiner
- Otomatik Makina
- Máquinas automáticas
- Aparate
- Automaattinen Machinery



GSI Group 217-226-4421

DC-2161

DC-2161

DC-2161 is located on the inside and outside of the roof access hatches.

Size: 8.860" x 5.910"

Quantity: 2



GSI Group 217-226-4421


DC-2163

DC-2163



DC-2163 is located on the outside and inside of the main power panel doors.

Size: 3.940" x 1.970"

Quantity: 3




- Automatic Machinery
- Automatické stroje a zařízení
- Automatik Machinery
- автоматични машини
- automatische machines
- Автоматические машины
- автоматичні машини
- Automātiskā Mašīnas
- Automatinis Machinery
- machines automatiques
- Maquinaria automática
- macchine automatiche
- automatiska maskiner
- Otomatik Makina
- Máquinas automáticas
- Aparate
- Automaattinen Machinery

GSI Group 217-226-4421 DC-2164

DC-2164

Background: White
 Size: 3.940" x 1.970"
 Colors: Black, ANSI Yellow and ANSI Blue





- Automatic Machinery
- Automatické stroje a zařízení
- Automatik Machinery
- автоматични машини
- automatische machines
- Автоматические машины
- автоматичні машини
- Automātiskā Mašīnas
- Automatinis Machinery
- machines automatiques
- Maquinaria automática
- macchine automatiche
- automatiska maskiner
- Otomatik Makina
- Máquinas automáticas
- Aparate
- Automaattinen Machinery




GSI Group 217-226-4421 DC-2165

DC-2165

DC-2165 is located on the heat section inner and outer access hatches.
 Size: 3.940" x 5.910"
 Quantity: 2




GSI Group 217-226-4421 DC-2212


DC-2212

DC-2212 is located on the outside of the hopper service access hatch.
 Size: 5.000" x 3.000"
 Quantity: 2

2. Decals



- Automatic Machinery
- Automatické stroje a zařízení
- Automatikus Machinery
- автоматични машини
- automatische machines
- Автоматические машины
- автоматичні машини
- Automātiskā Mašīnas
- Automatinis Machinery
- machines automatiques
- Maquinaria automática
- macchine automatiche
- automatiska maskiner
- Otomatik Makina
- Máquinas automáticas
- Aparate
- Automaattinen Machinery



GSI Group 217-226-4421

DC-2214

DC-2214

DC-2214 is located on the grain sampling access hatch.

Size: 3.000" x 4.000"

Quantity: 1



GSI Group 217-226-4421


DC-2215

DC-2215

DC-2215 is located on the upper and middle level access hatches.

Size: 6.000" x 8.000"

Quantity varies with size of dryer.



GSI Group 217-226-4421

DC-2216

DC-2216

DC-2216 is located on the cool section (intake plenum) access hatch.

Size: 6.000" x 8.000"

Quantity: 1



GSI Group 217-226-4421

DC-2217

DC-2217

DC-2217 is located adjacent to the electrical lock out handle on the main power panel.

Size: 2.000" x 3.000"

Quantity: 1

- Automatic Machinery
- Automatické stroje a zařízení
- Automatikus Machinery
- автоматични машини
- automatische machines
- Автоматические машины
- автоматичні машини
- Automātiskā Mašīnas
- Automatinis Machinery
- machines automatiques
- Maquinaria automática
- macchine automatiche
- automatiska maskiner
- Otomatik Makina
- Máquinas automáticas
- Aparate
- Automaattinen Machinery



GSI Group 217-226-4421


DC-2230

DC-2230

Background: White

Colors: Black, ANSI Yellow and ANSI Blue

Size: 6.000" x 3.000"



GSI Group 217-226-4421

DC-2231

DC-2231

DC-2231 is located on the outside of the main power panel doors.

Size: 6.000" x 3.000"

Quantity: 2

2. Decals



GSI Group 217-226-4421



DC-2232

DC-2232

DC-2232 is located on roof panels adjacent to roof steps.
Size: 4.875" x 3.000"
Quantity: 4



GSI Group 217-226-4421



DC-2235

DC-2235

DC-2235 is located on the inside and outside main power panel door.
Size: 4.875" x 3.000"
Quantity: 2



GSI Group 217-226-4421

- All maintenance procedures must be performed by qualified personnel who are familiar with the operation of this equipment.
- Failure to observe this warning can result in serious or even fatal injury and/or equipment damage.

- If an overload or a fault current interruption occurs, circuits must be checked to determine the cause of the interruption.
- If a fault condition exists, the current-carrying components should be examined and replaced if damaged, and the integral current sensors must be replaced.
- To maintain overcurrent short circuit and ground fault protection, the manufacturer's instructions for selecting overload relays and setting the instantaneous trip circuit breaker must be followed.
- Be sure that charge light and all LED's are out before touching any components.
- All test equipment should be connected and disconnected with power off.
- Ground test equipment, such as oscilloscopes, may damage the inverter.
- Isolate all instruments from ground before using. The DC bus remains charged for several minutes after power is removed.

DC-2305

DC-2305

DC-2305 is located on the inside main power panel door.
Size: 6.000" x 5.250"
Quantity: 1

For precise location of all safety decals, please refer to manual provided with the language pack for the dryer.

Dryer Specifications

Models	1050	1260	1575	1875	20100	24100
Blower Size	43" Axial	43" Axial	8490	8542	8542	8600
Blower RPM	1750	1750	1035	856	981	818
Blower kW	37.50	45.00	56.25	56.25	75.00	75.00
Metering kW	0.75	0.75	0.75	0.75	0.75	0.75
Drying m ³ /s	19.98	22.86	36.42	38.63	46.57	51.15
Cooling m ³ /s	6.85	8.27	18.21	19.32	23.28	25.58
Grain Column	324 mm	324 mm	324 mm	324 mm	324 mm	324 mm
Tower Diameter	3.65 m	3.65 m	3.65 m	3.65 m	3.65 m	3.65 m
Overall Height	13.9 m	15.9 m	18.0 m	21.0 m	23.1 m	26.1 m
Wet Holding (T)	7.67	7.67	7.67	7.67	7.67	7.67
Heat Holding (T)	15.49	19.20	23.22	29.41	31.90	38.07
Cool Holding (T)	5.56	6.81	7.75	8.99	11.46	12.70
Dryer Holding (T)	31.29	36.25	41.20	48.64	53.59	60.99
Outside Catwalks	0	0	1	2	2	3
T/H (20%-15%)	25	30	38	46	51	61
T/H (25%-15%)	15	18	23	27	30	37

Electrical

Standard voltages are:

1. 240V, 480V or 575V, 60 Hz
2. 380V, 400V or 415V, 50 Hz

The power panel includes:

1. Main power disconnect.
2. Motor starters and overloads (standard direct on line, star/delta and soft start are options).
3. Control circuit breakers for the individual blower motors.
4. Auxiliary 7.5 kW motor starters for dry and wet grain handling equipment.
5. A correctly designed power supply is required, including safety earth connection.

Please note that the figures given [on Page 79](#) are minimum figures and do not take into account starting currents. Please allow for these when designing the required power supply for the dryer.

3. Specifications

Minimum Electrical Power Requirements

3 Phase Power Requirements (A)							
Supply Voltage	230	380	400	415	440	460	575
Model #							
T-1050	204	123	117	113	106	102	81
T-1260	226	136	130	125	118	113	90
T-1575	258	156	148	143	135	129	103
T-1875	258	156	148	143	135	129	103
T-20100	316	191	181	175	165	158	126
T-24100	316	191	181	175	165	158	126
F-1050	204	123	117	113	106	102	81
F-1260	226	136	130	125	118	113	90
F-1575	258	156	148	143	135	129	103
F-1875	258	156	148	143	135	129	103
F-20100	316	191	181	175	165	158	126
F-24100	316	191	181	175	165	158	126

Fuel

1. Fuel types are LPG or natural gas vapor.
2. Minimum supply pressure is,
 - a. 350 mBar natural gas at full burner flow rate.
 - b. 350 mBar LPG vapor at full burner flow rate. Higher pressures may be required to obtain maximum burner output.
3. Burner flow rates are as table on [Page 27](#).

T-Series and F-Series Fuel Specifications

T-Series and F-Series	T/F-1050	T/F-1260	T/F-1575	T/F-1875	T/F-1054	T/F-20100	T/F-24100
Maximum Burner Output (kW)	3254	3831	4882	5180	6244	6858	7722
Average Burner Output (kW)	1871	2203	2807	2979	3590	3943	4440
LPG Fuel	LPG Gross CV		93.8 MJ/m³				
Maximum Gas Flow LPG (m ³ /h)	125	147	187	199	240	263	296
Average Gas Flow LPG (m ³ /h)	72	85	108	114	138	151	170
Supply Pressure (mBar ¹)	350-700	350-700	350-700	350-700	350-700	350-700	350-700
Regulator Setting (mBar ²)		206	206	206	206	206	206
Regulator Spring	Black	Cadmium	Cadmium	Cadmium	Cadmium	Cadmium	Cadmium
Burner Pressure High-Fire mm (H ₂ O ⁶)		418	1375	807	1189	1447	972
Burner Pressure Low-Fire mm (H ₂ O ⁷)		16.7	55.0	32.3	47.5	57.9	38.9
Natural Gas Fuel	NG Gross CV		39 MJ/m³				
Maximum Gas Flow NG (m ³ /h)	303	357	455	483	582	640	720
Average Gas Flow NG (m ³ /h)	174	205	262	278	335	368	414
Supply Pressure (mBar ¹)	350-700	350-700	350-700	350-700	350-700	350-700	350-700
Regulator Setting (mBar ²)	21	206	206	206	206	206	206
Regulator Spring	Black	Cadmium	Cadmium	Cadmium	Cadmium	Cadmium	Cadmium
Burner Pressure High-Fire mm (H ₂ O ⁶)		719	1189	697	1009	1241	855
Burner Pressure Low-Fire mm (H ₂ O ⁷)		28.8	47.6	27.9	40.3	49.7	34.2
Pressure Relief Set Point (mBar ⁴)	500	500	500	500	500	500	500
Over Pressure Valve Set Point (mBar ⁵)	450	450	450	450	450	450	450

Dimensions




Figure 3A 1050




Figure 3B 1260

Dimensions (Continued)




Figure 3C 1575




Figure 3D 1875

Dimensions (Continued)




Figure 3E 20100




Figure 3F 24100

Dryer Layout

System Layout

When considering dryer location make allowance for:

1. Grain handling systems.
2. Location of storage bins.
3. Wet grain supply.
4. Prevailing wind direction.
5. Fuel and power supply.
6. Noise.
7. Control panel location.

Site Location

Do not locate the dryer:

1. Inside a building.
2. Adjacent to combustible material which may be sucked in.
3. Within 2.0 m of other structures. Refer to specifications [on Pages 25-27](#) and dimensions [on Pages 28-30](#).

You may need to obtain local permission for the dryer construction and should also consider:

1. Electrical code.
2. Fuel installation regulations.
3. Insurance requirements.

Foundation

Standard foundation details are given in [Figure 4A on Page 32](#) and [Figure 4B on Page 33](#). For ground conditions outside of these standards a local engineer will be required to carry out site specific foundation design.

Standard Base for Models 1050, 1260, 1575, 1875 and 20100



Standard Base for Model 24100




Figure 4B

4. Dryer Installation

Fuel Connections

LPG Dryers with Internal Vaporizers

The dryer is designed to operate on liquid LPG with gross calorific value of 93.8 MJ/m³. The fuel supplier should provide liquid fuel from the tank to intake point at the strainer on the dryer pipe train.

Natural Gas (NG) Dryers

The dryer is designed to operate on natural gas with gross calorific value of 39.0 MJ/m³. The dryer is equipped with a natural gas supply pipe system connected to the heater solenoid valves. A regulated pressure of 700 mBar must be provided at the connection to the dryer, with gas available in sufficient volume to maintain operating pressure.

Commissioning Checks

Before starting the dryer check:

1. Pressure tightness.
2. Over pressure valve operation.
3. Pressure relief operation.
4. Maximum pressure switch operation.

Electrical Connection

1. Power supply must be adequate for the full current draw, plus starting loads for the electrical equipment on the dryer.
2. Power is connected into the main disconnect in the dryer power panel.
3. The dryer must be properly earthed (grounded), which may require the installation of a suitable ground rod. This must be designed and carried out by a suitably qualified electrician in accordance with local regulations and codes and taking into account site ground conditions.
4. Earth connection should be made into the PE terminal in the power panel and to a suitable location on the dryer structure.
5. The electrical installer should carry out full electrical safety checks including earth continuity during commissioning of the dryer.

Connecting Auxiliary Conveyors

Auxiliary load and unload equipment can be wired directly to the dryer.

1. Maximum power not to exceed 7.5 kW.
2. Larger than 7.5 kW must be powered from an alternative source and contactor, though control may be run through the dryer control panel.

Vision Control Panel Layout




Figure 5A

Ref #	Description
1	Control Power Switch
2	Fan Switch
3	Heater Switch
4	Load Auger Switch
5	Unload Auger Switch

Ref #	Description
6	Operator Light Switch
7	Start Switch
8	Stop Switch
9	Meter Roll Speed
10	Touch Screen



Switches on the vision panel are for control purposes only. For servicing and maintenance switch OFF and lock at the main disconnect.

Vision controls are used on several GSI drying products. It can operate any dryer in either a batch or a continuous flow mode. All operating instructions for the T-Series dryer describes **continuous flow** operation only.

5. Operating Controls

1. **CONTROL POWER switch** turns ON/OFF power to the control.
2. **FAN switch** starts/stops the fan. AUTO position is not used on T-Series and F-Series dryers.
3. **HEATER switch** turns the heater ON/OFF. AUTO position is not used on T-Series and F-Series dryers.
4. **LOAD AUGER switch** selects operating mode wet fill conveyor. In AUTO and MANUAL, the wet fill conveyor operates to keep the dryer full. In AUTO only the dryer shuts down if it is low on grain for a pre-set period.
5. **UNLOAD switch** controls 'Accutrol' metering system and unload conveyor. In MANUAL, the metering system operates at the speed set by the METERING ROLL SPEED switch. In AUTO, it runs in multi-speed mode, controlled by the automatic moisture control.
6. **OUTSIDE LIGHT switch** controls the service light. In AUTO, the light is ON while the dryer is running and OFF when shut down.
7. **START switch** starts and operates the dryer.
8. **STOP switch** stops all dryer functions except the blower which will continue to run for 15 minutes after the stop has been pressed. To stop the blower before this time, turn the BLOWER switch to OFF.

The STOP switch is also used to re-set after a shut down.

Boot screen appears when the control power is switch ON. (See Figure 6A.)




Figure 6A

Default operation screen opens when START DRYER is pressed.




Figure 6B

6. Vision Touch Screen Display

1. **Dryer operation animation** shows the status of the fan/heaters, load and unload augers and meter rolls. Also grain temperature, moisture content, M/C set point and tones counter.
2. **Dryer status** indicates if the dryer is stopped, started, loading or unloading.
3. **Dryer status chart** shows the grain temperature, moisture in/out, temperature out and metering roll speed. Over a period of time.
4. **Plenum** shows the plenum temperature set point (SP), actual plenum temperature and burner status.
5. **Setup buttons** provides access to timers, temperature set points, dryer model and moisture control setup.




Figure 6C

Select Data Log Sample Time

To change the sample time:

1. Press modify.
2. Select required time.
3. Press Accept/Exit.

To clear the table, press Clear Table button. ([See Figure 6C.](#))

Optional Operation Screen



Press View button give four (4) options. (See Figure 6D.)



Figure 6D

1. **Table view:** Default operation screen view. (See Figure 6B on Page 37.)

2. **Graph view:**

a. Press  then .

b. Press any of  to select which data is graphed.


c. Press  to select time period.

3. **Owner's manual:** See Page 45.

4. **History:** See Page 46.

6. Vision Touch Screen Display

Setting the Timers

Press  to open the timers screen. (See Figure 6E.)











Figure 6E

1. Press  to set the load system delay during unload. Reduces load motor cycling.
2. Press  to set the dryer shut down delay after the OUT OF GRAIN switch opens. Set to the maximum time for the dryer to refill during drying (this is displayed during loading on the screen).
3. Press  to set the time between sequential fan starts (multiple fan dryers only).
4. Press  to set the unload system overrun following metering system shut down (allows unload system to clear itself).

5. Use  when setting timers. Note default values may be entered.

6. Press  then  to return to the operation screen. (See Figure 6B on Page 37.)

Setting the Temperatures

1. Press  to display temperature setup screen. (See Figure 6F.)









Figure 6F

2. Press  then use key pad to alter plenum temperature.
3. Press  then use key pad to alter grain temperature.

Note default units are °F. This can be changed to °C in SETUP.

4. Press  then  to return to the operation screen. (See Figure 6B on Page 37.)

The Setup Screen

Press  **Setup** adjust other dryer settings.











Figure 6G

1.  select continuous flow or staged batch drying modes.
2.  adjust time and date settings.
3.  select correct dryer model an details, as follow:
 - a. Number fan/heaters = 1
 - b. Load system = end
 - c. Dryer length (ft.) = 22 (Models 1875, 20100 and 24100)
18 (Models 1050, 1260 and 1575)
 - d. Number modules = 1
 - e. Fuel = LP
4.  [See Page 64](#) for detailed setup.

5.  changes between SI and American units.
6.  see service section on [Page 72](#).
7.  burner mode should be ALL HIGH/LOW. ([See Figure 6H.](#))





Figure 6H

8.  to adjust the switching range of the burner. ([See Figure 6I on Page 44.](#)) Default is 3°F (1°C). Tower dryers have just 1 plenum.

6. Vision Touch Screen Display





Figure 6I

9.  allows the dryer throughput meter to be calibrated on [Figure 6J](#).
Setting = (Actual tons per hour/Recorded tons per hour)*100





Figure 6J

Viewing the Owner's Manuals on the Display Screen

Press  then the Owner's Manual button. (See Figure 6K.)

At the explorer screen, double press the manual and wait for it to open on screen.




Figure 6K

Use the scroll bar to navigate the manual. (See Figure 6L.)





Figure 6L

Viewing the Dryer Shut Down History

Press  and then history. (See Figure 6M.)




Figure 6M

The shut down history is displayed and can be copied to a flash disc for viewing on another computer.



BEFORE STARTING THE DRYER. All safety guards must be in place. All personnel must stay away from the dryer. All access doors must be closed.

Dryer Commissioning

Electrical

1. Carry out earth bonding test per EN60204 and/or local electrical laws and regulations.
2. Check adequate power supply. (Refer to table [on Page 27.](#))
3. Voltage at phases must be within 5% of rated voltage.
4. Voltage drop must not exceed 5% when under full load.
5. Check overload settings for each motor circuit.
6. Complete full electrical tests in accordance with EU directives and local laws, regulations and codes.

Gas Train

1. Pressure test
 - a. Close inlet valve. ([See Figure 7F on Page 56.](#))
 - b. Close firing valve. ([See Figure 7I on Page 59.](#))
 - c. Close pilot line valve. ([See Figure 7G on Page 57.](#))
 - d. Fit pressure test nipple into main solenoid inlet flange.
 - e. Attach hand bellows and pressure gauge.
 - f. Pressurize gas train with air to 35 kPa (350 mBar).
 - g. Check for pressure loss at gauge.
 - h. Use leak detection to test for leaks.
 - i. Repeat on outlet flange.
 - j. Repeat on pilot line.
2. Set inlet pressure per table [on Page 27.](#)
3. Set relief valve per table [on Page 27.](#)
 - a. Apply air pressure via main solenoid inlet flange.
 - b. Increase/decrease spring pressure in relief valve.
 - c. Valve should open at 50 kPa maximum.

Dryer Commissioning (Continued)

4. Set over pressure shut off (OPSO) per table [on Page 25](#).
 - a. Apply air pressure via main solenoid inlet flange.
 - b. Increase/decrease spring pressure in OPSO.
 - c. Valve should shut at 45 kPa maximum.
5. Set operational pressure per table [on Page 27](#).
 - a. Open main gas valve.
 - b. Adjust pressure at regulator.
6. Set pilot flow rate.
 - a. Close pilot line manual shut off valve. ([See Figure 7G on Page 57.](#))
 - b. Close 'firing valve' on main gas line. ([See Figure 7I on Page 59.](#))
 - c. Start blowers.
 - d. Start burners.
 - e. When pilot solenoid valve opens, adjust flow rate to give pilot pressure of 4 kPa.
 - f. Adjustment is on pilot solenoid valve. ([See Figure 7A.](#))
 - g. Open pilot line manual shut off valve. ([See Figure 7G on Page 57.](#))
 - h. Re-set burner control. (It will have gone to lock out after previous attempt to light.) Reset can be done by cycling the burner switch on the PLC panel.
 - i. Start burner.
 - j. Pilot should now light and stay alight. After 10 seconds, main valve should open and after further 4 seconds burner control revert to lock out and pilot extinguish (main flame is shut off). If pilot does not stay alight, then the pressure and/or flame rod will need to be adjusted to ensure the burner control is getting a strong flame current. See [Step 7 on Page 49](#).




Figure 7A Pilot Valve Flow Adjustment

Dryer Commissioning (Continued)

7. Checking pilot flame current.

- a. The minimum flame signal, measured at the burner control, should be 1.25 VDC.
- b. Flame signal can be checked at the Honeywell burner control, located in the main power panel, as shown in [Figure 7C on Page 50](#).
- c. Flame rod may be re-positioned or gently bent to get better contact with the flame. Ensure rod is well clear of burner to prevent grounding when hot. Be careful not to damage ceramic insulator surrounding flame rod. ([See Figure 7B.](#))
- d. Check burner is properly grounded.
- e. Check neutral supply to burner control is 0 VAC.




Figure 7B Burner End Plate, Spark, Pilot and Flame Rod Locations

Ref #	Description
A	Main Gas
B	UV Sensor Connection (Optional)
C	Spark Ignitor
D	Flame Rod Locations
D*	Flame Rod Alternate Locations
E	Pilot Gas

NOTE: Minimum acceptable flame signal is 1.25 VDC.

Dryer Commissioning (Continued)



Figure 7C Honeywell Test Flame


Ref #	Description
A	Flame Simulator Test Jack
B	Negative (-) Meter Lead
C	Positive (+) Meter Lead
D	One Mega Ohm/volt Meter

8. Set burner high-fire pressure.
 - a. Re-open main gas 'firing valve'. *(See Figure 7I on Page 59.)*
 - b. Note required high-fire pressure from table *on Page 27.*
 - c. Set plenum temperature to approximately 100°C above ambient.
 - d. Light burners.
 - e. Check modulating valve has driven fully open.
 - f. Read pressure at burner gauge. *(See Figure 7I on Page 59.)*
 - g. Adjust pressure a regulator to give required pressure.
 - h. Lock regulator.

Dryer Commissioning (Continued)

9. Set burner low-fire pressure.
 - a. Set plenum temperature to approximately 5°C above ambient.
 - b. Light burners.
 - c. On low-fire, adjust modulating valve minimum setting to give pressure as per table [on Page 25](#).
10. Read pressure at burner gauge. [\(See Figure 7I on Page 59.\)](#)
11. Run burners and check burner modulates correctly.
12. Check gas pressure remains stable.
13. Fill out gas train commissioning check sheet. [\(See Page 4.\)](#)

Pre-Season Checks

1. Inspect the accutrol metering system.
 - a. Open the two (2) access doors and inspect the sweep metering system to ensure that the system is able to move freely.
2. Gas train
 - a. Check for any leaks by pressurizing the line with air and using gas leak disclosing solution or by doing pressure loss tests.
 - b. Leaks must be rectified by opening and resealing the joint.
3. Wiring
 - a. Check wiring on the dryer and inside the control panels for signs of damage or loose connections. Rectify any faults.
4. Electrical power
 - a. Check all circuit breakers in the panel are closed.
 - b. Turn ON the electrical power supply to the dryer.
 - c. Check for correct voltage on all phases.
5. CONTROL POWER switch
 - a. Turn the CONTROL POWER switch to ON.
 - b. At boot screen appears [\(See Figure 6A on Page 37\)](#), press  .
 - c. Any faults will be displayed on the Main screen.
 - d. If no faults are found safe, the START switch will illuminate.

Pre-Season Checks (Continued)

6. START switch
 - a. Check all selector switches are OFF.
 - b. Push the DRYER START switch.
 - c. Selector switches be activated.
7. Fuel check
 - a. Open the gas supply to the dryer.
 - b. Check correct supply pressure. (*See Table on Page 27.*)
8. Load auger. With grain supply OFF.
 - a. Start and stop load auger to check correct operation and rotation.
 - b. Turn the load auger to AUTO and allow to run for 8 minutes.
 - c. Dryer should stop and display OUT OF GRAIN error message.
 - d. Press STOP to clear message.
9. Unload operation
 - a. Turn unload auger to AUTO. Check correct operation and rotation.
 - b. Turn unload auger to MANUAL position. Check correct operation and rotation.
10. Accutrol sweep metering system operation
 - a. With unload in AUTO, check metering speed increases and decreases as control is adjusted.
 - b. Turn unload OFF. Unload will continue for 60 seconds and shut down.
11. FAN switch
 - a. Turn FAN switch to ON the OFF and check correct operation and rotation.
12. Burner safety
 - a. Turn fuel OFF.
 - b. Start the fan.
 - c. Turn HEATER switch to ON.
 - d. Burner should attempt to light and then lockout.
 - e. Display should read "Ignition Failure Fan 1".

Pre-Season Checks (Continued)

13. Burner test fire

- a. Turn fuel ON.
- b. Set plenum temperature to 60°C.
- c. Start the fan.
- d. Turn HEATER switch to ON.
- e. After purge the burner should light.
- f. Adjust the pressure regulator to required burner pressure. *(See Table on Page 27.)*
- g. Lock the regulator.
- h. When the plenum reaches set point, adjust the MINIMUM setting on the modulating valve *(See Figure 71 on Page 59)* to the required setting. *(See Table on Page 27.)*
- i. Allow the burner to cycle between high and low and stabilize at the set point.
- j. Fine adjustment may be needed to obtain good temperature modulation.

14. Dryer shut down

- a. Short term shut down.
 - Turn burner OFF.
 - Turn fan OFF.
 - Turn load OFF.
 - Turn unload OFF.
 - Close main fuel valve.
- b. Long term shut down.
 - Close the fuel supply and allow the burner to burn out.
 - Turn all selector switches to OFF.
 - Turn control power OFF.
 - Disconnect main power.

15. Emergency PRESS EMERGENCY STOP.

Tower Dryer Pipe Train Assembly




Figure 7D Tower Dryer Pipe Train (2" Shown)

Ref #	Description
A	Inlet Section (See Page 55.)
B	Regulator Section (See Page 56.)
C	Pilot Section (See Page 57.)
D	Safety Shut Off Section (See Page 58.)
E	Modular Section (See Page 59.)

Inlet Section




Figure 7E *Inlet Section*

Ref #	Description
A	Manual Shut Off
B	Inlet Pressure Gauge
C	Filter
D	Test Point
E	Union

Regulator Section




Figure 7F *Regulator Section*

Ref #	Description
A	Nipple
B	OPSO Adjuster
C	OPSO Sensing Line
D	Regulator Sensing Line
E	Pressure Relief
F	Pilot Line
G	Test Point
H	Pressure Gauge
I	Union
J	Sensing Line Trim Valve
K	Pressure Regulator
L	Over Pressure Shut Off (OPSO)

Pilot Section




Figure 7G *Pilot Section*

Ref #	Description
A	Nipple
B	Pilot Shut Off Valve (Manual)
C	Pressure Gauge
D	Pilot Line Double Safety Shut Off Solenoid Valve
E	Pilot Flow Adjuster
F	Pilot Pressure Gauge
G	Manual Shut Off
H	Pilot Line Connection Point
I	Pilot Low Pressure Switch

Safety Shut Off Section




Figure 7H Safety Shut Off Section

Ref #	Description
A	Nipple
B	Low Pressure Switch
C	Double Safety Shut Off Solenoid Valve
D	Pressure Gauge
E	Union
F	High Pressure Switch
G	Valve Proving System
H	Din Flange

Modulator Section




Figure 71 Modulator Section (Modulating motor not shown.)

Ref #	Description
A	Nipple
B	Maxon Valve Motor
C	Pressure Gauge
D	Firing Valve
E	Connection to Burner Line
F	Drain Point (Valve not shown.)

8. Dryer Start-Up and Operation

Drying Temperatures

Drying temperatures differ from crop to crop. Please check the drying temperature does not risk damage to the crop before proceeding.

1. Shelled corn moisture content of 20%-30% (93°C-104°C).
2. Small grain (wheat, oats, barley, milo), 65°C-90°C.
3. Soybeans 50°C-60°C.

Initial Setup Parameters

With the control power ON and the dryer control screen visible.

1. Timer and delay settings: Follow procedures in [Setting the Timers on Page 40](#) to set.
 - a. Load timer.
 - b. Out of grain (OOG) timer.
 - c. Fan delay timer.
 - d. Unload delay timer.

Use default settings as a starting point and adjust subsequently if required.

2. Setting the temperatures. Follow procedure in [Setting the Temperatures on Page 41](#) to set.
 - a. Plenum temperature.
 - b. Grain temperature.

Start-Up



BEFORE STARTING THE DRYER. All safety guards must be in place. All personnel must away from the dryer. All access doors must be closed.

1. Make sure pre-season checks have been carried out.
2. Start the control system, with all selector switches OFF.
3. At boot screen ([See Figure 6A on Page 37](#)), press
4. Turn load auger to MANUAL.
5. Press Start button.
6. Allow dryer to fill.



The dryer is now ready to begin drying.

Continuous Flow Drying Mode Using Advanced Moisture Control

7. Press  and set dryer to CONTINUOUS FLOW. Press .

8. Press .




Figure 8A

8. Dryer Start-Up and Operation

9. Set minimum unload rate to 10% and maximum to suit the unload equipment.
10. Set plenum temperature management ON to reduce risk of over-drying when unload rates are limited by a low maximum unloading rate.
11. Return to Moisture Control window and set grain type. Optional printer may also be setup.




Figure 8B

12. Turn UNLOAD switch OFF.
13. Open fuel supply.
14. Turn LOAD AUGER switch to AUTO.
15. Refer to drying tables [on Pages 66-71](#). Select the initial unload rate for the dryer model, drying temperature and moisture content. Example: Model 1575 drying wheat from 18% to 13% at 80°C initial unload rate = 60.
16. Turn FAN to ON.
17. Turn HEATER to ON.
18. If the dryer is filled with wet grain, let the fan and heater run for 6 minutes per 1% of moisture to be removed.

Example: 18% - 13% = 5% removal. Time = 5 (%) x 6 (min.) = 30 minutes.

This step is only required at initial start-up. Re-starting with dry grain, omit this step.
19. Then, turn UNLOAD AUGER to MANUAL and set the METER ROLL SPEED, (MANUAL SPEED). To do this push on the meter roll adjustment knob and turn to set initial unload rate. Grain should start to run.






Figure 8C

20. Take three (3) samples with an accurate moisture meter and calculate the average moisture. Calibrate the wet and dry grain sensors until the on screen reading agrees with the average. To do this:

- Press  .
- Press  .
- Calculate difference between actual moisture reading and that on screen.
- Increase or decrease the on screen reading by the calculated difference.

Example:

Actual = 17%;

On screen = 18.3%.

Difference = Actual - On screen = -1.3%

Enter -1.3% in the calibration screen.

8. Dryer Start-Up and Operation




Figure 8D

21. Turn UNLOAD to AUTO. Advanced moisture control is now active.



Figure 8E

22. Set the target moisture and let the dryer run. Make no more changes to allow the system to stabilize.
23. The dryer runs in MANUAL for 30 minutes being switched to AUTO to ensure grain is flowing evenly. The screen displays a timer to show remaining time to full AUTO control.

How the Advanced Moisture Control Works

1. Wet and dry moisture and grain temperature are continually monitored.
2. Control action is mainly based on the dry sensor.
3. Grain flow is increased or decreased to maintain the required dry moisture.
4. The wet sensor and the column grain temperature sensor are intended to detect moisture spikes coming into the dryer so that the moisture controller can react ahead of time. If the wet sensor detects a jump of moisture coming into the dryer, the controller will slow down the unload speed immediately. This process is gradual, to prevent over-drying.
5. MANUAL control is use at the start of drying to allow the controller to gather sufficient information to adequately control.

IMPORTANT: *Once drying has commenced DO NOT make frequent adjustments to drying parameters. This will cause control instabilities and result in over or under drying. Allow the controller to manage the dryer.*

9. Drying Time Tables

Model 1050

Corn

Moisture		75°C	88°C	100°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
17%	15%	71	83	95
18%	15%	54	63	72
19%	15%	44	51	58
20%	15%	37	43	50
21%	15%	32	38	43
22%	15%	29	33	38
23%	15%	25	30	34
24%	15%	23	26	30
25%	15%	20	24	27
26%	15%	18	21	24
27%	15%	16	19	22
28%	15%	15	17	20
29%	15%	13	15	18
30%	15%	12	14	16
32%	15%	10	12	13
35%	15%	8	9	11

Wheat, Barley, Milo

Moisture		60°C	70°C	80°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	50	59	70
16%	13%	38	44	53
17%	13%	31	36	43
18%	13%	26	31	37
19%	13%	23	27	32
20%	13%	20	24	28
21%	13%	18	21	25
23%	13%	14	17	20
25%	13%	11	13	16

Soybeans

Moisture		50°C	55°C	60°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	57	66	74
16%	13%	43	49	55
17%	13%	35	40	45
18%	13%	30	34	38
19%	13%	26	29	33
20%	13%	23	26	29
21%	13%	20	23	26

Model 1260**Corn**

Moisture		75°C	88°C	100°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
17%	15%	85	99	--
18%	15%	65	75	86
19%	15%	53	61	69
20%	15%	44	51	60
21%	15%	38	45	51
22%	15%	35	39	45
23%	15%	30	36	40
24%	15%	27	31	36
25%	15%	24	29	32
26%	15%	22	25	29
27%	15%	19	23	26
28%	15%	18	20	24
29%	15%	16	18	21
30%	15%	14	17	19
32%	15%	12	14	15
35%	15%	10	11	13

Wheat, Barley, Milo

Moisture		60°C	70°C	80°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	60	70	83
16%	13%	45	53	63
17%	13%	37	43	51
18%	13%	31	37	44
19%	13%	27	32	38
20%	13%	24	28	33
21%	13%	21	25	30
23%	13%	17	20	24
25%	13%	14	16	19

Soybeans

Moisture		50°C	55°C	60°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	68	78	88
16%	13%	51	58	65
17%	13%	41	47	53
18%	13%	35	40	45
19%	13%	31	35	39
20%	13%	27	31	35
21%	13%	24	28	31
23%	13%	19	22	25
25%	13%	15	18	20

9. Drying Time Tables

Model 1575

Corn

Moisture		75°C	88°C	100°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
17%	15%	--	--	--
18%	15%	89	--	--
19%	15%	72	85	97
20%	15%	62	72	82
21%	15%	53	62	71
22%	15%	47	55	63
23%	15%	42	49	56
24%	15%	37	44	50
25%	15%	33	40	45
26%	15%	30	35	40
27%	15%	27	31	36
28%	15%	24	28	32
29%	15%	22	26	29
30%	15%	20	23	26
32%	15%	17	19	22
35%	15%	13	15	17

Wheat, Barley, Milo

Moisture		60°C	70°C	80°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	83	97	--
16%	13%	63	73	87
17%	13%	51	60	71
18%	13%	44	51	60
19%	13%	38	44	53
20%	13%	33	39	46
21%	13%	30	35	41
23%	13%	24	28	33
25%	13%	19	22	26

Soybeans

Moisture		50°C	55°C	60°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	95	--	--
16%	13%	71	81	91
17%	13%	57	66	74
18%	13%	49	56	63
19%	13%	43	49	55
20%	13%	38	43	48
21%	13%	33	38	43

Model 1875**Corn**

Moisture		75°C	88°C	100°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
17%	15%	92	--	--
18%	15%	69	81	92
19%	15%	56	66	75
20%	15%	48	56	64
21%	15%	42	48	56
22%	15%	37	43	49
23%	15%	33	38	43
24%	15%	29	34	39
25%	15%	26	30	35
26%	15%	23	27	31
27%	15%	21	24	28
28%	15%	19	22	25
29%	15%	17	20	23
30%	15%	15	18	21
32%	15%	13	15	17
35%	15%	10	12	14

Wheat, Barley, Milo

Moisture		60°C	70°C	80°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	65	76	90
16%	13%	49	57	68
17%	13%	40	47	55
18%	13%	34	40	47
19%	13%	29	34	41
20%	13%	26	30	36
21%	13%	23	27	32
23%	13%	18	21	26
25%	13%	15	17	21

Soybeans

Moisture		50°C	55°C	60°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	74	84	95
16%	13%	55	63	71
17%	13%	45	51	57
18%	13%	38	43	49
19%	13%	33	38	43
20%	13%	29	34	38
21%	13%	26	30	34
23%	13%	21	24	27
25%	13%	17	19	21

9. Drying Time Tables

Model 20100

Corn

Moisture		75°C	88°C	100°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
17%	15%	--	--	--
18%	15%	79	92	--
19%	15%	65	75	86
20%	15%	55	64	73
21%	15%	48	56	64
22%	15%	42	49	56
23%	15%	37	44	50
24%	15%	33	39	44
25%	15%	30	35	40
26%	15%	27	31	36
27%	15%	24	28	32
28%	15%	22	25	29
29%	15%	19	23	26
30%	15%	18	21	24
32%	15%	15	17	20
35%	15%	12	14	16

Wheat, Barley, Milo

Moisture		60°C	70°C	80°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	74	87	--
16%	13%	56	65	78
17%	13%	46	53	63
18%	13%	39	45	54
19%	13%	34	39	47
20%	13%	30	35	41
21%	13%	27	31	37
23%	13%	21	25	29
25%	13%	17	20	24

Soybeans

Moisture		50°C	55°C	60°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	85	97	--
16%	13%	63	72	81
17%	13%	51	58	66
18%	13%	44	50	56
19%	13%	38	43	49
20%	13%	34	38	43
21%	13%	30	34	38
23%	13%	24	27	31
25%	13%	19	22	25

Model 24100**Corn**

Moisture		75°C	88°C	100°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
17%	15%	--	--	--
18%	15%	91	--	--
19%	15%	74	86	99
20%	15%	63	73	84
21%	15%	55	64	73
22%	15%	48	56	64
23%	15%	43	50	57
24%	15%	38	44	51
25%	15%	34	40	45
26%	15%	31	36	41
27%	15%	27	32	37
28%	15%	25	29	33
29%	15%	22	26	30
30%	15%	20	24	27
32%	15%	17	20	22
35%	15%	13	16	18

Wheat, Barley, Milo

Moisture		60°C	70°C	80°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	85	99	--
16%	13%	64	75	89
17%	13%	52	61	73
18%	13%	44	52	62
19%	13%	39	45	54
20%	13%	34	40	47
21%	13%	30	36	42
23%	13%	27	28	37
25%	13%	19	23	27

Soybeans

Moisture		50°C	55°C	60°C
In	Out	% Unload Rate	% Unload Rate	% Unload Rate
15%	13%	97	--	--
16%	13%	72	82	92
17%	13%	58	67	75
18%	13%	50	57	64
19%	13%	43	50	56
20%	13%	38	44	49
21%	13%	34	39	44
23%	13%	27	31	35
25%	13%	22	25	28



BEFORE SERVICING THE DRYER. Turn OFF and LOCK electrical power at the MAIN DISCONNECT. Turn off fuel supply.

Pre-Seasonal Inspection and Service

1. Inspect control panels for loose wires, rodent damage and accumulated foreign material. Clean and repair as required.
2. Lubricate the blowers, motors and metering system as per lubrication table on [Page 75](#).
3. Check blower belts tension.
4. Inspect and clean the burner. Check that holes in the stainless steel air mixing plates are clear. Clean if required.
5. Check connections to flame rod and spark plug. Clean or replace if necessary.
6. Check gas train drain valve and drain any accumulated water. Close before dryer operation.
7. Check the discharge area is cleaned of stalks and old grain. Inspect the sweeps for excessive wear.
8. Remove covers from burner.

IMPORTANT: *The covers to the discharge sections on the tower dryers must be in place and clamped down at all times when the dryer is in operation. If the cover is off during operation, the vacuum created by the blowers will suck foreign matter from the discharge area and deposit it in the heat section of the dryer plugging the inside screens of the dryer also creating a fire hazard.*

See pre-season check list on [Page 74](#).

Seasonal Inspection and Service

1. Follow lubrication guides in the lubrication table on [Page 75](#).
2. Keep the cooling chamber floor clear of dust and dirt. Check each day before starting drying. Failure to do so could result in a fire. Dirt can be swept into the unload systems.
3. Keep the heat section clear of dust or dirt. Check the hopper divider that separates the heat section from the cooling section to ensure that it remains clean and open.
4. Check the grain discharge area on the dryer. On 'Accutrol' sweep dryers check the sweeps for trash or stalk build ups that could be obstructing grain flow.
5. The dryer is not intended to be a grain storage structure. Storing grain in the dryer for extended periods of time can result in plugged grain columns, torn or stretched perforated dryer wall sheets, and can place undue structural stress on the interior rolled plenum channels that form the roundness of the dryer. During the drying season, if the dryer is only being operated occasionally, the metering system on the dryer must be operated for five minutes every other day to make sure that the grain in the drying columns remains loose and free flowing. If a weather event such as rain or snow storm occurs when the dryer is full of grain, the dryer must be operated the next day to make sure that the wet grain does not swell up in the drying columns.
6. If the perforated outer sheets on the dryer have become excessively dirty, they may need to be washed off to prevent inhibited airflow.

In Case of Fire

1. Hit emergency stop.
2. Shut off power.
3. Shut off fuel.
4. Do not try to cool a fire by running fan(s).
5. Never run grain from the dryer into the elevator or storage if a fire is known or suspected.
6. Locate the area of the fire.
7. If safe to do so, tackle the fire with a suitable extinguisher. Check for secondary fires.
8. Emergency discharge slide gates at the bottom of each column as well as easy access gates located near the hopper discharge area permit fast dumping of each individual grain column.
9. If in doubt call the fire department.

End of Season Service

1. Empty the dryer at the end of the drying season. The dryer must not be used for grain storage. Grain left in the dryer will compact, can become wet, swell, and/or spoil. This can result in plugged grain columns, torn or stretched perforated dryer wall sheets, and can place undue structural stress on the dryer's interior rolled plenum channel rings.
2. Shut off electrical power and lock.
3. Shut off gas/fuel supply and lock.
4. Clean out the plenum roof grain cushion and remove any grain that may be hanging up on the plenum roof.
5. Make sure the grain exchangers are clean.
6. Clean out the hopper that divides the heat section from the cooling section.
7. Clean the cooling chamber floor.
8. Remove all grain and trash from the metering drum floor. This grain can be raked out by hand by opening the slide gates located in the hopper bottom of the dryer.
9. Make sure gas supply is shut off to the dryer.
10. Open the gas train drain valve located on the bottom of the gas train.
11. Cover the burner with a tarpaulin or plastic.

Pre-Season Service Check List

- ___ Lubricate blower bearings.
- ___ Lubricate blower motor bearings, if needed.
- ___ Check blower belts and adjust if necessary.
- ___ Clean burner ports.
- ___ Inspect flame rod and spark ignitor.
- ___ Check oil levels in gearboxes.
- ___ Inspect divider hopper between heat and cooling section. Clean if necessary.
- ___ Inspect bindicator grain level switches.
- ___ Inspect metering system access door cover seals.
- ___ Lubricate metering system access door cover hold-down latches.
- ___ Lubricate modulator motor linkage.
- ___ Check butterfly operation in modulating valve.
- ___ Check gas pressure gauges.
- ___ Check interior of maxon shut off valves for corrosion. Clean if necessary.
- ___ Clean control and power panels, tighten loose connections and check for leaks.
- ___ Inspect metering systems. Clean accumulated stalks and old grain.
- ___ Start-up dryer and check operating controls.
- ___ Other: Itemize _____

End of Season Shut Down Procedure

- ___ Start unload and empty all grain from dryers.
- ___ Clean out grain cushion (on plenum roof under fill spout). Clean plenum roof.
- ___ Clean off grain exchangers.
- ___ Clean out divider hopper, between heating and cooling section.
- ___ Clean inside cooling sheets and cooling floor.
- ___ Remove all grain and trash from unload section of dryer.
- ___ Open emergency grain discharge doors (and drain doors in Zimmerman dryers).
- ___ Open drain valve in gas train.
- ___ Cover burner with a tarp or plastic sheeting.

Location	Instructions	Type of Lubrication	Lubrication Interval
Accutrol (sweep unload) top and bottom drive bearings.	Lubricate slowly until lube shows through seal. Wipe clean.	High quality, grade #2 lithium based grease.	Beginning of season (annually).
Accutrol (sweep unload) coupling hub.	Remove the two (2) lube plugs from the cover. Lubricate slowly until grease begins seeping through relief plug.	High quality, grade #2 lithium based grease.	Beginning of season (annually).
Blower shaft bearings.	Lubricate bottom bearing plug slowly counting the grease gun pump until lube shows through the seal. Wipe clean. Use same # of grease gun pumps for top bearing.	High quality, grade #2 lithium based grease.	Every 4 weeks of dryer operation.
Blower motor bearings.	See motor lubrication procedure below .	High quality, grade #2 lithium based grease.	Every 2 years. (Normal operation, ever 8-10 months continuous operation.)
Metering variable speed drive motor.	See motor lubrication procedure below .	High quality, grade #2 lithium based grease.	Every 2 years. (Normal operation, ever 8-10 months continuous operation.)
Accutrol gearbox.	Grease filled gearbox. Replenish grease to the first stage (upper) reduction mechanism through grease fitting provided (typically quantity = 0.3 oz. of grease).	High quality, grade #2 lithium based grease.	Beginning of season (annually).
*Lubrication of motors - Operate motor for 20 minutes. Clean grease fitting. Remove grease relief plug and using a low pressure grease gun, pump in the required grease. After re-lubricating, allow motor to run for 10 minutes before replacing relief hardware. DO NOT over grease.			

12. Error Messages

Safety Circuit Shut Down Messages

Shut down warning window: Touch the Help button to display the shut down help window. (See Figure 12A.)




Figure 12A

Fan/Heater Generated Errors

Air Switch Stuck

Switch is stuck closed when fan is OFF.

Fan Loss of Airflow

Air switch has stopped sensing air pressure during fan operation.

Fan No Airflow

Air switch is not sensing air pressure after fan start-up.

Flame Loss

Flame signal was lost during burner operation.

Grain Temp Short

Grain temperature sensor is showing short circuit.

Grain Overheat

Grain temperature has exceeded 100°C. Grain flow may be blocked or metering speed too slow. This re-sets once cooled, but the burner must be re-cycled to enable re-start.

Housing High-Limit

Heater housing has exceeded 93°C and burner has locked out. This must be manually re-set once the cause has been removed.

Ignition Failure

Burner failed to light. Burner control will lock-out and must be re-set. Check flame sensor.

Illegal Flame

Burner control is seeing flame when burner is OFF. Check for leaking safety valve. Check for fire.

Motor Overload

Motor thermal overload has opened load on one or other motor. Must be manually re-set.

Vapor High-Limit

LPG vapor has exceed safe temperature and burner has locked out. Vaporizer may need to be adjusted. Burner must be re-set before it will relight.

Input/Output Generated Errors

Air System Failure

Safety on an air conveying system (integrated into the dryer safety circuit) has opened. The air system safety connections are located in the upper control box on the terminal strip on terminal J1-10 on the Input/Output board and must see 12 VDC.

Aux Load Overload

The motor overload relay has tripped on the aux load motor circuit located in the upper control box.

Aux Unload Overload

The motor overload relay has tripped on the aux unload motor circuit located in the upper control box.

Load Motor Overload

The motor overload has tripped on the load motor overload located in the upper control box.

Meter Rolls Failed

Metering rolls are not turning.

Out of Grain

The dryer has run low on grain and the out of grain timer has timed out, shutting the dryer down.

12. Error Messages

Unload Motor Overload

The motor overload has tripped on the unload motor overload located in the upper control box.

User Safety

On CE dryers this safety indicates that the valve proving system has failed to prove the main safety valves. Valves may need to be replaced or be re-seated.

Master Display Generated Errors

Cont-Batch Mode Chng

Dryer was switch from continuous flow to batch or vice versa whilst running.

Network Failed FH x

Network communications have been lost to the Fan/Heater board. Check cables. ([See Figure 12B.](#))

Network Failed Input/Output

Network connections have been lost between the Main I/O and Lower control box board. Check cables.

Network Failed Mast

Network connections have been lost between Master Display board (lower control panel) and Input/Output board (upper control panel door) and the Fan/Heater boards. Check cables.




Figure 12B

Plenum Temp Open x

Plenum temperature sensor is showing open circuit.


Plenum Temp Short x

Plenum temperature sensor is showing short circuit.

Plenum x Overheat

Plenum has exceeded 154°C and burner has locked out.


Upper Terminal Strip Wiring




Burner/Fan Control Wiring




Lower Terminal Strip Wiring



Safety Relay Wiring




Upper Terminal Strip Field Connections




13. Wiring Diagrams for Pactrol Burner Control

Lower Terminal Strip Field Connections




Upper Terminal Strip Wiring



14. Wiring Diagrams for Honeywell Burner Control


Burner/Fan Control Wiring




TERMINALS ON UPPER TERMINAL STRIP

CR1 --- SP01 12 VDC SAFETY RELAY
 CR2 --- SP01 12 VDC SAFETY RELAY
 CR3 --- SP01 12 VDC SAFETY RELAY
 CR4 --- SP01 12 VDC SAFETY RELAY
 CR5 --- SP01 12 VDC SAFETY RELAY
 CR6 --- SP01 12 VDC SAFETY RELAY
 CR7 --- SP01 12 VDC SAFETY RELAY
 CR8 --- SP01 12 VDC SAFETY RELAY
 CR9 --- SP01 12 VDC SAFETY RELAY
 CR10 --- SP01 12 VDC SAFETY RELAY
 CR11 --- SP01 12 VDC SAFETY RELAY
 CR12 --- SP01 12 VDC SAFETY RELAY
 CR13 --- DP01 120 VAC SAFETY RELAY


Lower Terminal Strip Wiring



Safety Relay Wiring




Upper Terminal Strip Field Connections



14. Wiring Diagrams for Honeywell Burner Control

Lower Terminal Strip Field Connections



Limited Warranty - N.A. Grain Products

The GSI Group, LLC. ("GSI") warrants products which it manufactures, to be free of defects in materials and workmanship under normal usage and conditions for a period of 12 months from the date of shipment (or, if shipped by vessel, 14 months from the date of arrival at the port of discharge). If, in GSI's sole judgment, a product is found to have a defect in materials and/or workmanship, GSI will, at its own option and expense, repair or replace the product or refund the purchase price. This Limited Warranty is subject to extension and other terms as set forth below.

Warranty Enhancements: The warranty period for the following products is enhanced as shown below and is in lieu of (and not in addition to) the above stated warranty period. (Warranty Period is from date of shipment.)

	Product	Warranty Period
Storage	Grain Bin Structural Design	5 Years
	• Roof, doors, platforms and walk arounds	
	• Flooring (when installed using GSI specified floor support system for that floor)	
Conditioning	• Hopper tanks	5 Years
	Dryer Structural Design - (Tower, Portable and TopDry)	
	• Includes (frame, portable dryer screens, ladders, access doors and platforms)	
	All other Dryer parts including:	
Material Handling	• Electrical (controls, sensors, switches and internal wiring)	2 Years
	Bullseye Controllers	2 Years
	Bucket Elevators Structural Design	5 Years
	Towers Structural Design	5 Years
	Catwalks Structural Design	5 Years
	Accessories (stairs, ladders and platforms) Structural Design	5 Years

Conditions and Limitations:

THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE LIMITED WARRANTY DESCRIPTION SET FORTH HEREIN; SPECIFICALLY, GSI DISCLAIMS ANY AND ALL OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE IN CONNECTION WITH: (I) ANY PRODUCT MANUFACTURED OR SOLD BY GSI, OR (II) ANY ADVICE, INSTRUCTION, RECOMMENDATION OR SUGGESTION PROVIDED BY AN AGENT, REPRESENTATIVE OR EMPLOYEE OF GSI REGARDING OR RELATED TO THE CONFIGURATION, INSTALLATION, LAYOUT, SUITABILITY FOR A PARTICULAR PURPOSE, OR DESIGN OF SUCH PRODUCTS.

The sole and exclusive remedy for any claimant is set forth in this Limited Warranty and shall not exceed the amount paid for the product purchased. This Warranty only covers the value of the warranted parts and equipment, and does not cover labor charges for removing or installing defective parts, shipping charges with respect to such parts, any applicable sales or other taxes, or any other charges or expenses not specified in this Warranty. GSI shall not be liable for any other direct, indirect, incidental or consequential damages, including, without limitation, loss of anticipated profits or benefits. Expenses incurred by or on behalf of a claimant without prior written authorization from the GSI warranty department shall not be reimbursed. This warranty is not transferable and applies only to the original end-user. GSI shall have no obligation or responsibility for any representations or warranties made by or on behalf of any dealer, agent or distributor. Prior to installation, the end-user bears all responsibility to comply with federal, state and local codes which apply to the location and installation of the products.

This Limited Warranty extends solely to products sold by GSI and does not cover any parts, components or materials used in conjunction with the product, that are not sold by GSI. GSI assumes no responsibility for claims resulting from construction defects, unauthorized modifications, corrosion or other cosmetic issues caused by storage, application or environmental conditions. Modifications to products not specifically delineated in the manual accompanying the product at initial sale will void all warranties. This Limited Warranty shall not extend to products or parts which have been damaged by negligent use, misuse, alteration, accident or which have been improperly/inadequately maintained.

Notice Procedure:

In order to make a valid warranty claim a written notice of the claim must be submitted, using the RMA form, within 60 days of discovery of a warrantable nonconformance. The RMA form is found on the OneGSI portal.

Service Parts:

GSI warrants, subject to all other conditions described in this Warranty, Service Parts which it manufactures for a period of 12 months from the date of purchase unless specified in Enhancements above.

(Limited Warranty - N.A. Grain Products_ revised 19 October 2018)

This equipment shall be installed in accordance with the current installation codes and applicable regulations, which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.



**1004 E. Illinois St.
Assumption, IL 62510-0020
Phone: 1-217-226-4421
Fax: 1-217-226-4420
www.gsiag.com**

