

Farm/Commercial Distributor

Instruction Manual

PNEG-1385

Date: 10-03-08







Contents

Chapter 1	Introduction	4
Chapter 2	Safety	5
Chapter 3	Installation Notes	8
Chapter 4	Maintenance Replacing the Wear Liner Greasing the Bearing Replacing the Brush Mount Assembly	10 10
Chapter 5	Parts List DFB06445GL - 6" 4 Hole, 45° Distributor Assembly DFB06645GL - 6" 6 Hole, 45° Distributor Assembly DFB06845GL - 6" 8 Hole, 45° Distributor Assembly DFB08845GL - 8" 6 Hole, 45° Distributor Assembly DFB08845GL - 8" 8 Hole, 45° Distributor Assembly DFB081045GL - 8" 10 Hole, 45° Distributor Assembly DFB10645GL - 10" 6 Hole, 45° Distributor Assembly - Drawing A DFB10645GL - 10" 6 Hole, 45° Distributor Assembly - Drawing B DFB10845GL - 10" 8 Hole, 45° Distributor Assembly DFB101045GL - 10" 10 Hole, 45° Distributor Assembly DFB12445GL - 12" 4 Hole, 45° Distributor Assembly DFB12445GL - 12" 6 Hole, 45° Distributor Assembly DFB12845GL - 12" 8 Hole, 45° Distributor Assembly DFB121045GL - 12" 10 Hole, 45° Distributor Assembly DFB14445GL - 14" 8 Hole, 45° Distributor Assembly DFB14645GL - 14" 6 Hole, 45° Distributor Assembly DFB14645GL - 14" 8 Hole, 45° Distributor Assembly DFB14845GL - 14" 8 Hole, 45° Distributor Assembly	
Chapter 6	Warranty	31

1. Introduction

Thank you for choosing this product. It is designed to give excellent performance and service for many years.

This manual covers general information on the distributor installation. Due to the wide variety of field conditions we cannot cover every aspect of installation. We offer one method for installing equipment but, rely on the qualified contractor's experience and techniques. Some conditions and surroundings do not allow certain practices during the installation of equipment. We can not be responsible for the installation of the distributor and accessories. We encourage anyone installing, or maintaining this equipment to thoroughly read this manual before proceeding.

The company is the vendor of the distributor and certain of its optional accessories only, and does not assume responsibility for the installation. The installation recommendations contained within this manual are for consideration only.

READ THIS MANUAL carefully to learn how to properly use and install equipment. Failure to do so could result in personal injury or equipment damage.

INSPECT the shipment immediately upon arrival. The customer is responsible for ensuring that all quantities are correct. The customer should report and note any damage or shortage on the bill of lading to justify their claim to the transport company.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your equipment and should be easily accessible when needed.

A WARRANTY is provided as part of the company's support program for customers who use and maintain their equipment as described in the manual. The warranty is explained on the warranty page located on the inside back cover of this manual.

This warranty provides you the assurance that the company will back its products when defects appear within the warranty period. In some circumstances, the company also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the factory specifications, the warranty will become void and field improvements may be denied.

Safety Guidelines

This manual contains information that is important for you, the owner/operator, to know and understand. This information relates to protecting *personal safety* and *preventing equipment problems*. It is the responsibility of the owner/operator to inform anyone operating or working in the area of this equipment of these safety guidelines. To help you recognize this information, we use the symbols that are defined below. Please read the manual and pay attention to these sections. Failure to read this manual and its safety instructions is a misuse of the equipment and may lead to serious injury or death.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

NOTE

NOTE indicates information about the equipment that you should pay special attention.

Safety Instructions

Our foremost concern is your safety and the safety of others associated with this equipment. We want to keep you as a customer. This manual is to help you understand safe operating procedures and some problems which may be encountered by the operator and other personnel.

As owner and/or operator, it is your responsibility to know what requirements, hazards and precautions exist, and to inform all personnel associated with the equipment or in the area. Safety precautions may be required from the personnel. Avoid any alterations to the equipment. Such alterations may produce a very dangerous situation where SERIOUS INJURY or DEATH may occur.

This equipment shall be installed in accordance with the current installation codes and applicable regulations which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.


Follow Safety Instructions

Carefully read all safety messages in this manual and safety signs on your machine. Keep signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from the manufacturer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machinery in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual or need assistance, contact your dealer.




Read and Understand Manual

Prepare for Emergencies

Be prepared if fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital and fire department near your telephone.



Keep Emergency Equipment Quickly Accessible

Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Eye Protection



Remove all jewelry.

Long hair should be tied up and back.

Gloves



Safety glasses should be worn at all times to protect eyes from debris.

Steel Toe Boots



Wear gloves to protect your hands from sharp edges on plastic or steel parts.

Wear steel toe boots to help protect your feet from falling debris. Tuck in any loose or dangling shoe strings.

Respirator



A respirator may be needed to prevent breathing potentially toxic fumes and dust.

Wear hard hat to help protect your head.

Hard Hat



Wear appropriate fall protection equipment when working at elevations greater than six feet (6').

Fall Protection




*Sloped transitions are included with the following models:

- 1. DFB08845GLT (8" 8 Hole) 1 Foot offset sloped transition
- 2. DFB081045GLT (8" 10 Hole) 1 Foot offset sloped transition
- 3. DFB10645GLT (10" 6 Hole) 1 Foot offset sloped transition
- 4. DFB10845GLT (10" 8 Hole) 1 Foot offset sloped transition
- 5. DFB101045GLT (10" 10 Hole) 2 Feet offset sloped transition
- 6. DFB12445GLT (12" 4 Hole) 1 Foot offset sloped transition
- 7. DFB12645GLT (12" 6 Hole) 1 Foot offset sloped transition
- 8. DFB12845GLT (12" 8 Hole) 1 Foot offset sloped transition
- 9. DFB121045GLT (12" 10 Hole) 1 Foot offset sloped transition

Transition Numbers

GESLLNCEA006 16" x 12" Sloped discharge transition, 1' offset (1' Offset sloped transition = 1' drop and 1' horizontal movement)

GESLLNCEB006 16" x 12" Sloped discharge transition, 2' offset (2' Offset sloped transition = 2' drop and 2' horizontal movement)






Figure 3A Figure 3B

^{*}The offset transition allow clearance between the trunking and the distributor control wheel. The transition also keeps the distributor outlet spouting from interfering with the ladder safety cage. Transitions must be installed for proper distributor operation. (See Figure 3A and Figure 3B.)



If you must get inside of distributor, turn OFF and LOCK OUT all power sources. DO NOT operate the distributor while inside.



Crush hazard. Lifting lugs are to be used for placement only. DO NOT use lifting lugs for structural support. (See Figure 3C.)



DO NOT use a clamp band when attaching the down spout to the inlet flange. A bolted connection is required at this point. (See Figure 3C.)




Figure 3C

Replacing the Wear Liner

Position the spouting near the door. Remove the transition extension tube. (See Figure 4A.)
Remove the transition spout. (See Figure 4A.) Reverse the transition box which will allow access to the hardware holding the liner in. (See Figure 4B on Page 11). Replace the old liner with the new liner. (See Figure 4C on Page 11.) Replace the transition spout and transition extension tube.

Replacement Liner Numbers

8" - DFB0183, 10" - DFB0051, 12" - DFB0121

Greasing the Bearing

The bearing is greased at the factory and is ready for operation. Lubricate annually using a #2 lithium based grease or equivalent. (See Figure 4A.)




Figure 4A

Greasing the Bearing (Continued)




Figure 4B




Figure 4C

Replacing the Brush Mount Assembly

Position the spouting near the door. Remove the transition extension tube. (See Figure 4D.) Loosen the clamp band and remove old brush assembly from the transition extension tube. Replace the new brush assembly onto transition extension tube and tighten in place using the clamp band. Replace the transition extension tube/brush assembly.

NOTE: Make sure the seam of the brush assembly is facing towards the top as shown in Figure 4D. The brush bristles should be somewhat snug against the spout wall. Operate the spout to all outlets to ensure proper alignment and clearance.

Replacement Brush Assembly Numbers

8" - DFB0189, 10" - DFB0060, 12" - DFB0127





Figure 4D


- 1. DFB06445GL 6" 4 Hole, 45° Distributor Assembly
- 2. DFB06645GL 6" 6 Hole, 45° Distributor Assembly
- 3. DFB06845GL 6" 8 Hole, 45° Distributor Assembly
- 4. DFB08645GL 8" 6 Hole, 45° Distributor Assembly
- 5. DFB08845GL 8" 8 Hole, 45° Distributor Assembly
- 6. DFB081045GL 8" 10 Hole, 45° Distributor Assembly
- 7. DFB10645GL 10" 6 Hole, 45° Distributor Assembly Drawing A
- 8. DFB10645GL 10" 6 Hole, 45° Distributor Assembly Drawing B
- 9. DFB10845GL 10" 8 Hole, 45° Distributor Assembly
- 10. DFB101045GL 10" 10 Hole, 45° Distributor Assembly
- 11. DFB12445GL 12" 4 Hole, 45° Distributor Assembly
- 12. DFB12645GL 12" 6 Hole, 45° Distributor Assembly
- 13. DFB12845GL 12" 8 Hole, 45° Distributor Assembly
- 14. DFB121045GL 12" 10 Hole, 45° Distributor Assembly
- 15. DFB14445GL 14" 4 Hole, 45° Distributor Assembly
- 16. DFB14645GL 14" 6 Hole, 45° Distributor Assembly
- 17. DFB14845GL 14" 8 Hole, 45° Distributor Assembly

DFB06445GL - 6" 4 Hole, 45° Distributor Assembly




DFB06645GL - 6" 6 Hole, 45° Distributor Assembly


DFB06845GL - 6" 8 Hole, 45° Distributor Assembly




DFB08645GL - 8" 6 Hole, 45° Distributor Assembly




DFB08845GL - 8" 8 Hole, 45° Distributor Assembly



DFB081045GL - 8" 10 Hole, 45° Distributor Assembly




DFB10645GL - 10" 6 Hole, 45° Distributor Assembly - Drawing A




DFB10645GL - 10" 6 Hole, 45° Distributor Assembly - Drawing B

				3 Flange		rade 5 Plated	l Grade 5		ZN Grade 5		Grade 2		DP Grade 2		0	dment			ZN Grade 5			no		Grade 5	ZN Grade 2		Drawing No.	DFB10645GL
Description	10" 6 Hole Body Weldment	10" Inlet Sleeve Weldment	Door/Hinge Assembly	Bearing 1-1/2" Dodge 4B SC Flange	doff	Bolt HHCS 3/8"-16 x 3/4" Grade 5 Plated	Nut Flange Whiz 3/8"-16 ZN Grade 5	Flat Washer 1/2" SAE	Bolt HHCS 1/2"-13 x 1-1/2" ZN Grade	1/2"-13	Bolt HHCS 3/8"-16 x 1" ZN Grade	3/8"-16	Flat Washer 3/8" USS ZN YDP Grade	haft	Spring Pin 1/4" x 2-1/2" Long	Transition Box Support Weldment	Transition Box Spacer Plate	10" Transition Box w/ Liner	Bolt HHCS 3/8"-16 x 1-1/2" ZN Grade	Index Tube Assembly	10" 6 Hole Index Plate	10" Transition Tube Extension	10" Brush/Mount Assembly	Bolt HHCS 3/8"-16 x 1" ZN Grade	Bolt HHCS 3/8"-16 x 1-1/2" ZN Grade 2		Ship N/A	Scale NONE Work to Dimensions Do Not Scale
	10" 6 Hole	10" Inlet SI	Door/Hinge	Bearing 1-	Index Standoff	Bolt HHCS	Nut Flange	Flat Washe	Bolt HHCS	Nylock Nut 1/2"-13	Bolt HHCS	Nylock Nut 3/8"-16	Flat Washe	Indexing Shaft	Spring Pin	Transition	Transition	10" Transiti	Bolt HHCS	Index Tube	10" 6 Hole	10" Transiti	10" Brush//	Bolt HHCS	Bolt HHCS		Sheet 2 of 2	Date
ğ	-	_	-	-	-	12	30	4	4	4	2	9	10	-	ო	-	4	-	4	1	-	-	-	16	2		height dex	rawn hecke
	DFB0001	DFB0035	DFB0032	KD-PBA0003	DFB0038	S-7105	S-968	S-2120	S-8760	S-8260	S-7520	S-7383	S-248	DFB0045	S-9288	DFB0040	DFB0043	DFB0015	S-7515	DFB0050	DFB0039	DFB0024	DFB0060	S-7469	S-7521		TOLERANCES W	Fractions +/- 1/32" B Decimals +/- 0.031 C Angles +/- 1.00
Ref #	-	2	ო	4	5	9	7	8	6	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	7		
							((24))"	_		4		(22)	×<			>	() ()	67	2					25 (23)	10" 6 HOLE. 45°	DISTRIBUTOR ASSEMBLY
								(15)	ო)—				_	<	<u> </u>												THE GSI GROUP	Engineerir
							((19)	4	/						\	1	\		/		·				88		Date By
									(7)	<u>s</u>	10																	Revision Description
																					~			<u>.</u>		4		No.


DFB10845GL - 10" 8 Hole, 45° Distributor Assembly




DFB101045GL - 10" 10 Hole, 45° Distributor Assembly



DFB12445GL - 12" 4 Hole, 45° Distributor Assembly




DFB12645GL - 12" 6 Hole, 45° Distributor Assembly




DFB12845GL - 12" 8 Hole, 45° Distributor Assembly

1 DEBOURD 1 DEBOURD 1 DEBOURD 1 DEBOURD 2 DEBOURD	Description	Body Weldment	Inlet Sleeve Weldment	Bolt HHCS 3/8"-16 x 3/4" Grade 5 Plated	Nut Flange Whiz 3/8"-16 ZN Grade 5	Bearing 1-1/2" Dodge 4B SC Flange	Flat Washer 1/2" SAE	Bolt HHCS 1/2"-13 x 1-1/2" ZN Grade 5	Nylock Nut 1/2"-13	Indexing Shaft	Transition Box Support Weldment	Transition Box Spacer Plate	Transition Box w/ Liner Assembly	Spring Pin 1/4" x 2-1/2" Long	Transition Tube Extension	Brush/Mount Assembly	Bolt HHCS 3/8"-16 x 1-1/2" ZN Grade 2	Index Standoff	Index Plate	Flat Washer 3/8" USS ZN YDP Grade 2	Index Tube Assembly	Door/Hinge Assembly	Bolt HHCS 3/8"-16 x 1" ZN Grade 2	Nylock Nut 3/8"-16	Bolt HHCS 3/8"-16 x 1-1/2" ZN Grade 5		20 19	Sheet 1 of 1	Date Work to Dimensions Do Not Scale
23 NOTE: Side panels removed in the parts. 3 An interest of the panels removed in the parts. 11 24 4 4 4 4 4 4 4 4 4 4 4 4	Qty	-	-	24	56	-	4	4	4	-	-	2	-	2	-	-	7	-	-	6	-	-	2	9	4			Weight ndex Drawn Sy	By Checke
23 NOTE: Side panels removed in the parts. 3 An interest of the panels removed in the parts. 11 24 4 4 4 4 4 4 4 4 4 4 4 4		DFB0100	DFB0136	S-7105	S-968	KD-PBA0003	S-2120	S-8760	S-8260	DFB0145	DFB0040	DFB0043	DFB0114	S-9288		-	S-7521	DFB0038	DFB0101		_	_	_	-	-		2 -	TOLERANCES (Unless Noted) Fractions +/- 1/32"	Angles +/- 1.00
3 3 12 12 12 12 14 15 16 16 16 16 16 17 16 18 18 18 18 18 18 19 18 18 18 18 18 18 18 18 18 18 18 18 18	Ref #	~	7	ဧ	4	2	ω	_	∞	თ	10	7	12	13	14	15	19	17	8	19	20	21	22	23	24	~ N			
23 6 6 14 4 14 8 8 8 6 6 6 14 Assumption, IL Engineering Division: Date By MATERIAL HANDLING													Concession of the Concession o	OIE: Side paneis removed	r viewing internal parts.							((15)),	_	2		12" 8 HOLE, 45°	RIBUTOR ASSEMB
	1												- 2	ZΥ	2				_	_ ,	_				1		4	(DIST


DFB121045GL - 12" 10 Hole, 45° Distributor Assembly




DFB14445GL - 14" 4 Hole, 45° Distributor Assembly



DFB14645GL - 14" 6 Hole, 45° Distributor Assembly



DFB14845GL - 14" 8 Hole, 45° Distributor Assembly



30



The GSI Group, LLC. ("GSI") warrants products which it manufactures to be free of defects in materials and workmanship under normal usage and conditions for a period of 12 months after sale to the original end-user or if a foreign sale, 14 months from arrival at port of discharge, whichever is earlier. The end-user's sole remedy (and GSI's only obligation) is to repair or replace, at GSI's option and expense, products that in GSI's judgment, contain a material defect in materials or workmanship. Expenses incurred by or on behalf of the end-user without prior written authorization from the GSI Warranty Group shall be the sole responsibility of the end-user.

Warranty Extensions: The Limited Warranty period is extended for the following products:

	Product	Warranty Period
AP Fans and	Performer Series Direct Drive Fan Motor	3 Years
Flooring	All Fiberglass Housings	Lifetime
	All Fiberglass Propellers	Lifetime
Cumbanana	Feeder System Pan Assemblies	5 Years **
Cumberland Feeding/Watering	Feed Tubes (1.75" & 2.00")	10 Years *
Systems	Centerless Augers	10 Years *
Systems	Watering Nipples	10 Years *
Grain Systems	Grain Bin Structural Design	5 Years
Grain Systems	Portable & Tower Dryers	2 Years
Farm Fans Zimmerman	Portable & Tower Dryer Frames and Internal Infrastructure †	5 Years

- * Warranty prorated from list price:

 0 to 3 years no cost to end-user
 3 to 5 years end-user pays 25%
 5 to 7 years end-user pays 50%
 7 to 10 years end user pays 75%
- ** Warranty prorated from list price: 0 to 3 years – no cost to end-user 3 to 5 years – end-user pays 50%
- † Motors, burner components and moving parts not included. Portable Dryer screens included. Tower Dryer screens not included.

GSI further warrants that the portable and tower dryer frame and basket, excluding all auger and auger drive components, shall be free from defects in materials for a period of time beginning on the twelfth (12th) month from the date of purchase and continuing until the sixtieth (60th) month from the date of purchase (extended warranty period). During the extended warranty period, GSI will replace the frame or basket components that prove to be defective under normal conditions of use without charge, excluding the labor, transportation, and/or shipping costs incurred in the performance of this extended warranty.

Conditions and Limitations:

THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE LIMITED WARRANTY DESCRIPTION SET FORTH ABOVE. SPECIFICALLY, GSI MAKES NO FURTHER WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE IN CONNECTION WITH: (i) PRODUCT MANUFACTURED OR SOLD BY GSI OR (ii) ANY ADVICE, INSTRUCTION, RECOMMENDATION OR SUGGESTION PROVIDED BY AN AGENT, REPRESENTATIVE OR EMPLOYEE OF GSI REGARDING OR RELATED TO THE CONFIGURATION, INSTALLATION, LAYOUT, SUITABILITY FOR A PARTICULAR PURPOSE, OR DESIGN OF SUCH PRODUCTS.

GSI shall not be liable for any direct, indirect, incidental or consequential damages, including, without limitation, loss of anticipated profits or benefits. The sole and exclusive remedy is set forth in the Limited Warranty, which shall not exceed the amount paid for the product purchased. This warranty is not transferable and applies only to the original end-user. GSI shall have no obligation or responsibility for any representations or warranties made by or on behalf of any dealer, agent or distributor.

GSI assumes no responsibility for claims resulting from construction defects or unauthorized modifications to products which it manufactured. Modifications to products not specifically delineated in the manual accompanying the equipment at initial sale will void the Limited Warranty.

This Limited Warranty shall not extend to products or parts which have been damaged by negligent use, misuse, alteration, accident or which have been improperly/inadequately maintained. This Limited Warranty extends solely to products manufactured by GSI.

Prior to installation, the end-user has the responsibility to comply with federal, state and local codes which apply to the location and installation of products manufactured or sold by GSI.

9101239_1_CR_rev7.DOC (revised July 2009)

This equipment shall be installed in accordance with the current installation codes and applicable regulations which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.





GSI Group 1004 E. Illinois St. Assumption, IL 62510-0020 Phone: 1-217-226-4421

Fax: 1-217-226-4420 www.gsiag.com